



# TECHNICAL BULLETIN

## AII METAL POLISH

Formulated to work quickly with Meguiar's® DynaCone™ wheel polishing tool, or by hand to turn dull, oxidized wheels & metal stunningly bright in just minutes!

**Part #:** G15308 – 236ml / 8 oz lotion  
G3400- 4 oz lotion- ONLY IN KIT

**Packaging:** 6 per case

**Features:**

- For all un-coated, polished, chrome, aluminum, stainless steel
- Creates a mirror finish

**pH:** 8.3 - 9

**Paintable:** Yes

**Dilution:** RTU (Ready to use)

**Application Method:** Rub on, wipe off

**Directions:** For best results, apply to cool surface. Shake well before & during use. Apply a small amount on Meguiar's® DynaCone™ polishing tool, a foam pad, a 100% cotton terry cloth towel or microfiber towel. Gently work the polish on the surface, re-applying product as needed. Do not allow product to dry. Remove with a clean microfiber or 100% cotton terry towel. Do not use on painted or clear-coated wheels, or chrome plated plastic . Test first in an inconspicuous area.

**Health rating:**

Health:	1
Fire:	2
Reactivity:	0
Specific Hazard:	N/A

FOR ADDITIONAL SAFETY INFORMATION, CONSULT MSDS  
KEEP OUT OF REACH OF CHILDREN